





Transferring Points Between Views



Projected Views



Projection Angle Method



Compass Method

Both methods acceptable for transferring the depth of the top view to the side view.